THERMALRIGHT

USER MANUAL

FROZEN WARFRAME SE

CAUTION!!! All liquid coolers has probability of leaking, please follow closely to instructions to install. ALWAYS check liquid coolerbefore installation. If there is anydefect or deformation to the cooler,please contactcustomer service immediately.

Customizable LCD Screen
High Performance Fan and Pump
Addressable RGB Lighting

REV1.0

www.thermalright.com

注意！！！任何水冷都有泄漏风险，请谨慎安装前请仔细检查，如果损坏或变形请立即联系售后客服进行更换！

FROZEN WARFRAME SE

用户手册

THERMALRIGHT

REV1.0

www.thermalright.com

THERMALRIGHT

www.thermalright.com

产品保修卡

产品名：	
产品型号：	
产品数量：	
购买日期：	
客户姓名：	
电话：	
地址：	

保修须知

1.保修卡须与购买发票一起保存，否则恕不提供保修。

2.保修卡上的产品型号、产品数量、购买日期、客户姓名、电话、地址必须填写清楚，否则恕不提供保修。

3.保修卡必须加盖销售商发票专用章，否则恕不提供保修。

4.在保修期内，产品因正常使用而发生故障，凭保修卡可享受免费维修。

5.因人为因素造成损坏，超出保修期，或无保修卡，恕不提供保修。

售后服务

服务电话：400-708-6776

服务邮箱：service@thermalright.com

地址：辽宁省沈阳市浑南区创新路29甲2号

邮编：110179

版权所有，未经许可，不得翻印。

FROZEN WARFRAME DISPLAY USER GUIDE

1.Check 9 pin USB cable connection between waterblock and motherboard before installing.

2.Download software at:
https://www.thermalright.com/support/download/
Unzip setup file and start install by double click setup.

3.After install completed, double click shortcut icon on desktop to run software.

4.All functions on LCD are controlled by software, and software will auto start at OS boot. Please do not exit the program.

5.For unknown error, restart the display by re-plug USB cable on waterblock.

www.thermalright.com

Rotate waterblock panel.

Magnetic Waterblock Panel can be adjusted to four directions.

www.thermalright.com

冷头上盖操作说明

冷头面板磁吸设计，可360°旋转

www.thermalright.com

LCD screen wiring

Connect screen power cable to SATA socket on power supply;Connect 9 pin USB cable to 9 pin USB socket on motherboard.



www.thermalright.com

屏幕接线

屏幕供电线使用SATA接口，数据传输线使用9针USB2.0跨接口

www.thermalright.com

Waterblock/Fan Guide

■ Connect the waterblock pump power cable to CPU_OPT or AIO PUMP socket

Connect waterblock to motherboard 9 pin USB socket with USB cable.

Connect fan power cable to CPU_FAN socket on motherboard

Connect FAN to motherboard 5V 3 pin socket with RGB cable.



www.thermalright.com

冷头/风扇安装说明

■ 请务必安装导热硅脂



www.thermalright.com

Fan&Radiator Mounting



Use long fan-mounting screws to install fans on the radiator.

Use short radiator mounting screws to install radiator to the case.

www.thermalright.com

风扇与冷排安装



www.thermalright.com

AMD AM4 / AM5 Installation



www.thermalright.com

AMD AM4/AM5 安装



www.thermalright.com

INTEL LGA1700/1851 Installation



www.thermalright.com

INTEL LGA1700/1851 安装

www.thermalright.com

INTEL LGA115X/1200 Installation

www.thermalright.com

INTEL LGA115X/1200安装



www.thermalright.com

INTEL LGA 115X/1700 安装背板



www.thermalright.com

INTEL LGA 115X/1700 Adjust intel backplate



www.thermalright.com

Components

Fan: 25CM
25DM
25EM
25DP
25EP
Thermal Compound*1
INTEL 1700 / 1851 Backplate Kit
AMD Backplate Kit
INTEL 115X / 1200 Backplate Kit
INTEL 1700 / 1851 Bracket Kit
INTEL 115X / 1200 Bracket Kit
AMD Bracket Kit
Screwdriver*1
Fan screw
Radiator screw
Fan clip
LGA 1700/1851 Standoffs
LGA 115X/1200 Standoffs
AMD Standoffs
LGA 1700/1851 Backplate Screws
LGA 115X/1200 Backplate Screws
AMD Backplate Screws
LGA 1700/1851 Screws
LGA 115X/1200 Screws
AMD Screws
LGA 1700/1851 Nuts
LGA 115X/1200 Nuts
AMD Nuts
LGA 1700/1851 Plastic Standoffs
LGA 115X/1200 Plastic Standoffs
AMD Plastic Standoffs
LGA 1700/1851 Screwdriver
LGA 115X/1200 Screwdriver
AMD Screwdriver
LGA 1700/1851 Nuts
LGA 115X/1200 Nuts
AMD Nuts
LGA 1700/1851 Screws
LGA 115X/1200 Screws
AMD Screws
LGA 1700/1851 Standoffs
LGA 115X/1200 Standoffs
AMD Standoffs
LGA 1700/1851 Backplate Screws
LGA 115X/1200 Backplate Screws
AMD Backplate Screws