


DEEPCOOL



FH-04


4 -Port Fan Hub

This installation guide is applicable for FAN HUB series.





PRODUCT SCHEMATIC DRAWING

How to Use



This fan hub supports up to 4 fans, PWM function compatible.
Note: The data of FAN1 can be obtained by BIOS or other software, PWM function is not available when 3-Pin port is applied.



- EN For more information, please check our website at: www.deepcool.com
- DE Für weitere Informationen besuchen Sie bitte unsere Website unter: www.deepcool.com
- FR Pour plus d'informations, merci de visiter notre site internet: www.deepcool.com
- ES Para más información, por favor, visite nuestra página en: www.deepcool.com
- IT Per ulteriori informazioni, visitate il nostro sito web: www.deepcool.com
- PT Para mais informação, visita o nosso website em: www.deepcool.com
- CS Další informace najdete na našich webových stránkách: www.deepcool.com
- SV För mer information, gå till vår hemsida på: www.deepcool.com
- PL Więcej informacji można znaleźć na naszej stronie internetowej: www.deepcool.com
- RU Больше информации на сайте: www.deepcool.com
- JA 詳細については、以下URL先の公式WEBサイトをご確認ください: www.deepcool.com
- KO 자세한 내용은 www.deepcool.com 에서 확인하실 수 있습니다
- AR على الموقع الإلكتروني www.deepcool.com ، يمكنك العثور على مزيد من المعلومات
- ZH 如需要更多信息，请浏览网站: www.deepcool.com

BEIJING JZFS SCI-TECH CO., LTD.

No.101, Floor 1-4, Building 10, Dijing Road 9, Haidian Dist., Beijing, China

© 2024 BEIJING JZFS SCI-TECH CO., LTD. All rights reserved.

"DEEPCOOL 4™" and other commercial identities are legitimate registered trademarks and commercial identities of the trademarks owner and its affiliates in China and other countries or regions.

Pictures on this package are for reference only, please refer to the actual product.