




# MOONDROP DISCDREAM<sup>ULTRA</sup> 2



①Screen display  
From left to right: track number, track duration  
From top to bottom: Shuffle, single/full directory loop/battery

②STOP  
Short press to STOP  
Long press to switch CD, PC  
Function displays on screen

③Play/Pause  
When it works as CD, it's Play/Pause function.  
When it works as PC mode, it's mute function,  
and the screen displays flashing "U00".



Frontal buttons, from left to right


④PRE/REW:  
Short press to switch to previous song;  
Long press to rewind.  
\* There is no rewind function in PC mode.

⑤Next /FF:  
Short press to switch to the next song;  
Long press to fast forward  
\* There is no fast forward function in PC mode.

⑦Volume:  
Short press to increase/decrease the volume by  
one level, long press to increase/decrease the  
volume continuously.

⑥Mode switching:  
Single loop/full directory loop/shuffle loop

The ports on the left side, from left to right




①3.5mm line-out  
Optical

②PO output

③4.4mm balanced output

The ports on the right side, from left to right



①Power switch

②Charging indicator:  
It shows green during charging,  
and turns to red after full charged.

③Charging interface/data interface

## Audio formats

Supported discs: CD/CD-R/CD-RW

Supported file formats: MP3, WMA, LC-AAC, OGG, FLAC, APE, WAV.

PC mode: PCM supports sampling rate from 44.1KHz to 384KHz; DSD supports sampling rate from 2.8224MHz to 11.2896MHz.

## Charging

The charging indicator shows green during charging, and turns to red after full charged.

## Audio formats

\* This product comes with a 12-month warranty from the date of shipment. Within the warranty period, any defects that occur under normal use will be repaired, replaced, or refunded free of charge.

\* If there is a defect in this product that qualifies for warranty coverage, please contact us at [moondrop\\_support@moondroplab.com](mailto:moondrop_support@moondroplab.com) and return it to our customer service.

\* This product is a precision electronic device. Please do not place it in humid, dusty, high-temperature, or low-temperature environments. Additionally, to prevent damage, do not pull, shock, or compress this product. Malfunctions caused by disconnection, housing deformation, water damage, dust intrusion, corrosion, or plug damage due to these reasons are not covered by after-sales service.

\* If the repair can not be provided due to product upgrades within the warranty, we will provide replacement service depending on the condition, and won't enjoy the warranty after replacement.

\* If the product has expired the warranty period, and due to product replacement, our company may not be able to provide repair service.

\* We will not be able to provide repair service if the device shell or core parts are seriously deformed due to external force.

\* The after-sales service period is generally 7-20 days (excluding transportation time), depending on the repair department.

\* About warranty of repair/replacement:

If confirming that the product issue is of the quality built after getting the quality inspections by MOONDROP after service, it will get repaired/replaced, at that time, the remaining warranty period will be prolonged to 60 days if it is less than or equal to 60 days; Meanwhile, it will be counted according to the original warranty period if the remaining warranty period more than 60 days.

## Warranty Card

\* For after-sales service, please refer to [After-sales Terms].

Fault description: .....

Purchase date: .....

Receiving Address: .....

Customer Name: .....

Contact Phone: .....

MOONDROP Technology Co., Ltd.  
Website: [moondroplab.com](http://moondroplab.com)

Address: Haixia Technology Industry Park, Wenjiang District, Chengdu

