



ENGLISH

HYDROMASSAGE FOOT SPA VT-1798

The hydromassage foot spa brings relief to tired legs and increases blood circulation in legs significantly. Air bubbles provide muscle relaxation. Infrared lamp enables heating of particular parts of your feet. Massage attachments supplied with the unit are intended for acupuncture massage.

DESCRIPTION

1. Operation mode switch «0-1-2-3»
2. Massage rollers
3. Protection lid
4. Air bubbles release openings
5. «MAX» maximum water level mark
6. Infrared lamp

ATTENTION!

For additional protection it is reasonable to install a residual current device (RCD) with nominal operation current not exceeding 30 mA. To install an RCD, contact a specialist.

SAFETY MEASURES

Before using the electrical appliance read this manual carefully and keep it for further reference.

Use the unit for its intended purpose only as specified in this manual. Mishandling the unit can lead to its breakage and cause harm to the user or damage to his/her property.

- Before switching the unit on, make sure that the mains voltage corresponds to the voltage specified on the unit body.

• Install the foot SPA only on a dry and flat surface.

• Install the unit in such a way that you can easily unplug it in case of any malfunction.

The heating element of the foot SPA does not heat up cold water, but only keeps the poured in water warm.

Attention! Do not plug or unplug the unit while your feet are in the water.

- Select the preferable operation mode using the switch (1):

— «0» — the unit is off;

— «1» — bubble massage;

— «2» — keeping warm + infrared light;

— «3» — infrared light + keeping warm + bubble massage.

Attention!

For additional protection it is reasonable to install a residual current device (RCD) with nominal operation current not exceeding 30 mA. To install an RCD, contact a specialist.

Safety measures

Before using the electrical appliance read this manual carefully and keep it for further reference.

Use the unit for its intended purpose only as specified in this manual. Mishandling the unit can lead to its breakage and cause harm to the user or damage to his/her property.

- Before switching the unit on, make sure that the mains voltage corresponds to the voltage specified on the unit body.

• Install the foot SPA only on a dry and flat surface.

• Install the unit in such a way that you can easily unplug it in case of any malfunction.

Cleaning and care

• Before pouring out the water make sure that the unit is switched off and unplugged.

• Lift the protection lid (3) up and pour the water out from the foot SPA.

• Rinse the bath with water and a neutral detergent.

• Do not immerse the foot SPA body, the power cord and the power plug into water or other liquids. Do not use the foot SPA near swimming pools or other containers filled with water.

• If the unit is dropped into water, unplug it immediately, and only then take it out of the water; apply to the nearest authorized service center for testing or repairing the foot SPA.

• Always unplug the unit when you are not using it and before you fill it with water, pour the water out, clean or move the unit.

• Do not stand in the foot SPA. Use it only while sitting.

• Do not cover the foot spa with a rug or blanket while using it.

• Do not use the unit when you are drowsy.

• Stop using the unit immediately if any discomfort, pain or foot skin irritation appears.

• Do not allow children to use the unit as a toy.

• During operation and breaks between operation cycles, the unit should be placed out of reach of children.

• The unit is not intended for usage by physically or mentally disabled persons (including children) or by persons lacking experience or knowledge if they are not under supervision of a person who is responsible for their safety or if they are not instructed by this person on the usage of the unit.

• For children safety reasons do not leave polyethylene bags used as a packaging unattended.

Attention! Do not allow children to play with polyethylene bags or packaging film. Danger of suffocation!

• Check the power cord and plug periodically.

• Do not use the unit if the foot SPA body, the power plug or the power cord is damaged.

• Do not attempt to repair the unit. Do not disassemble the unit by yourself, if any malfunction is detected or after it was dropped, unplug the unit and apply to any authorized service center from the contact address listed in the warranty certificate and on the website www.vitek.ru.

• To avoid damages, transport the foot SPA in the original package only.

• Keep the unit in a dry cool place away from children and disabled persons.

THE UNIT IS INTENDED FOR HOUSEHOLD USE ONLY, ITS COMMERCIAL USAGE AND USAGE IN PRODUCTION AREAS AND WORK SPACES IS PROHIBITED.

Safety measures

• The foot SPA should not be used in cases of: benign and malignant tumors, skin inflammation, vein inflammation and thrombosis, open and fresh wounds, bruises, skin lesions or varicose veins, do not use the foot SPA in cases of shin or joint pain, and in severe cases of diabetes.

If you are pregnant, consult your doctor before using the foot SPA.

Consult your doctor if you have cardiovascular diseases or oncological diseases, or if you have an installed pacemaker.

Stop the massage if you feel any discomfort.

To avoid burns people insensitive to heat are recommended to check the water temperature with a thermometer before filling the foot SPA.

Consult your doctor regarding any other questions you may have.

FEET HYDROMASSAGE

Using of the foot SPA brings the following positive effects:

- relaxation of tense muscles;

• tiredness relief and feeling of lightness of your legs;

• stimulation of blood circulation;

• increase of cell regeneration.

Usually the massage session should last not longer than 15-20 minutes. As desired, the foot massage can be performed once or twice a day, you can determine your comfortable massage time according to your sensations.

Make an approximately 15 minutes break before using the unit again.

RUSSIAN

ГИДРОМАССАЖНАЯ ВАННОЧКА ДЛЯ НОГ VT-1798

Гидромассажная ванночка приносит облегчение усталым ногам и способствует кровообращению в сосудах ног. Воздушные пузырьки способствуют расслаблению мышц. Инфракрасный излучатель освещает целенаправленный нагрев определенных частей ступней ног.

Массажные насадки, входящие в комплект поставки, применяются для проведения акупунктурного массажа.

ОПИСАНИЕ

1. Переключатель режимов работы «0-1-2-3»

2. Массажные ролики

3. Защитная крышка

4. Отверстия для выхода воздушных пузырьков

5. Метка максимального уровня воды «МАК»

6. Инфракрасный излучатель

ВНИМАНИЕ!

После транспортировки или хранения устройства при пониженной температуре необходимо выдержать его при комнатной температуре не менее трех часов.

• Полностью распакуйте гидромассажную ванночку и удалите упаковочные материалы, мешающие работе устройства.

• Проверьте целостность устройства, при наличии повреждений не пользуйтесь устройством.

• Перед включением убедитесь в том, что напряжение электрической сети соответствует рабочему напряжению устройства.

• Протрите внутреннюю и внешние поверхности слегка влажной тканью, после чего вытирея насухо.

• Убедитесь в том, что вилка сетевого шнура не вставлена в электрическую розетку.

• Поставьте вилку сетевого шнура на место, где она не попадет под ноги.

• Вставьте вилку сетевого шнура в электрическую розетку.

• Перед включением устройства убедитесь в том, что напряжение электрической сети соответствует напряжению, указанному на корпусе устройства.

• С помощью переключателя (1) включите желаемый режим работы:

— «0» — устройство выключено;

— «1» — пузырьковый массаж;

— «2» — поддержание температуры + инфракрасное излучение;

— «3» — инфракрасное излучение + поддержание температуры + пузырьковый массаж.

• Установите вилку сетевого шнура вилкой вилки.

