

REV:1.1

High Performance PWM Fan
High Liquid Flow Rate Pump
High Density Aluminum Fins

CAUTION!!!
All liquid coolers has probability of
leaking, please follow instructions to install. ALWAYS check
the cooler, please contact customer service immediately.

www.thermalright.com

Thermalright

USER MANUAL

FROZEN MAGIC DIGITAL

用户手册

FROZEN MAGIC DIGITAL

注意!!! 任何水冷都存在漏液风险, 请谨慎
按规定操作安装! 安装前请对水冷外观进行详细检查。
开箱检查如有外观变形请立即联系客服进行确认!

水冷专用的高性能PWM风扇
配备高流量 高性能水泵
新型大面积铝挤

REV: 1.1

www.thermalright.com

Thermalright

附件清单

240X2
280X2
360X3

风扇

A

B

C

D

E

F

G

H

I

J

K

L

M

www.thermalright.com

Components

240X2 280X2 360X3

fan

A

B

C

D

E

F

G

H

I

J

K

L

M

www.thermalright.com

INTEL LGA 115X/1700 Adjust intel backplate

Position 1 for LGA 1700 /1851

Position 2 for LGA 115X/1200

Adjust backplate screws position to your motherboard

www.thermalright.com

INTEL LGA 115X/1700 安装背板

安装位置1用于LGA 1700/1851系列
安装位置2用于LGA 115X/1200系列

将螺栓调整到对应主板所需的位置

1700安装孔

115X安装孔

www.thermalright.com

INTEL LGA115X/1200安装

115X安装孔

Install two Intel brackets on motherboard through backplate screws, secure brackets with four screws.

Secure waterblock on CPU IHS.

Apply thermal compound from front side of motherboard through backplate screws.

Install Intel backplate from back side of motherboard through backplate screws, secure brackets with four screws.

1700安装孔

Install four 1700 standards on motherboard through backplate screws, secure brackets with four screws.

Secure waterblock on CPU IHS.

Apply thermal compound from front side of motherboard through backplate screws.

Install Intel backplate from back side of motherboard through backplate screws, secure brackets with four screws.

www.thermalright.com

INTEL LGA115X/1200 Installation

115X安装孔

Install two Intel brackets on motherboard through backplate screws, secure brackets with four screws.

Secure waterblock on CPU IHS.

Apply thermal compound from front side of motherboard through backplate screws.

Install Intel backplate from back side of motherboard through backplate screws, secure brackets with four screws.

1700安装孔

Install four 1700 standards on motherboard through backplate screws, secure brackets with four screws.

Secure waterblock on CPU IHS.

Apply thermal compound from front side of motherboard through backplate screws.

Install Intel backplate from back side of motherboard through backplate screws, secure brackets with four screws.

www.thermalright.com

INTEL LGA1700/1851 Installation

1700安装孔

Install four 1700 standards on motherboard through backplate screws, secure brackets with four screws.

Secure waterblock on CPU IHS.

Apply thermal compound from front side of motherboard through backplate screws.

Install Intel backplate from back side of motherboard through backplate screws, secure brackets with four screws.

1700安装孔

Install four 1700 standards on motherboard through backplate screws, secure brackets with four screws.

Secure waterblock on CPU IHS.

Apply thermal compound from front side of motherboard through backplate screws.

Install Intel backplate from back side of motherboard through backplate screws, secure brackets with four screws.

www.thermalright.com

INTEL LGA1700/1851 安装

1700安装孔

Install four 1700 standards on motherboard through backplate screws, secure brackets with four screws.

Secure waterblock on CPU IHS.

Apply thermal compound from front side of motherboard through backplate screws.

Install Intel backplate from back side of motherboard through backplate screws, secure brackets with four screws.

1700安装孔

Install four 1700 standards on motherboard through backplate screws, secure brackets with four screws.

Secure waterblock on CPU IHS.

Apply thermal compound from front side of motherboard through backplate screws.

Install Intel backplate from back side of motherboard through backplate screws, secure brackets with four screws.

www.thermalright.com

AMD AM4/AM5 Installation

Remove factory CPU brackets and screws, KEEP the backplate

Install four AM4/AM5 standards on backplate

Secure two AM4/AM5 brackets with four screws.

Secure waterblock on CPU IHS.

Apply thermal compound from front side of motherboard through backplate screws.

Install Intel backplate from back side of motherboard through backplate screws, secure brackets with four screws.

1700安装孔

Install four 1700 standards on motherboard through backplate screws, secure brackets with four screws.

Secure waterblock on CPU IHS.

Apply thermal compound from front side of motherboard through backplate screws.

Install Intel backplate from back side of motherboard through backplate screws, secure brackets with four screws.

www.thermalright.com

AMD AM4/AM5 安装

移除原厂CPU支架, 保留背板, 使用AM4螺丝将AMD支架固定到背板

安装四个AM4/AM5支架到背板上

固定两个AM4/AM5支架到背板上

将水冷头压在水泵上, 将压杆扣具螺栓用螺丝刀锁紧

涂好导热膏, 然后将水冷头压在水泵上, 将压杆扣具螺栓用螺丝刀锁紧

安装Intel背板到主板背面, 通过背板螺丝固定Intel背板

1700安装孔

安装四个1700标准到主板上

将水冷头压在水泵上, 将压杆扣具螺栓用螺丝刀锁紧

涂好导热膏, 然后将水冷头压在水泵上, 将压杆扣具螺栓用螺丝刀锁紧

安装Intel背板到主板背面, 通过背板螺丝固定Intel背板

www.thermalright.com

风扇与冷排安装

使用风扇螺丝, 将风扇固定在水排上:

使用水排螺丝, 将水排固定在机箱上。

www.thermalright.com

Fan&Radiator Mounting

Use short radiator mounting screws to install fans on the radiator.

Use fan screws to fix fan on water block.

Use fan screws to fix fan on water block.

Use water block to fix fan on case.

www.thermalright.com

Waterblock/Fan Guide

Connect 9 pin USB cable to 9 pin USB socket on motherboard.

Connect 3 pin PWM/ARGB cable to 3 pin PWM/ARGB socket on motherboard.

Connect 3 pin ARGB cable to 3 pin ARGB socket on motherboard.

Connect 3 pin ARGB cable to 3 pin ARGB socket on motherboard.

www.thermalright.com

冷头/风扇使用说明

将水泵供电线接在主板CPU OPT或者AIO PUMP接口。风扇供电线接在主板CPU_FAN接口。

将风扇ARGB线与冷头RGB线并联, 接在主板3针ARGB接口, 即可通过主板灯光软件来控制灯光。

冷头数据总线接在主板USB2.0的D+D-针接口

将水泵供电线接在主板CPU OPT或者AIO PUMP接口。风扇供电线接在主板CPU_FAN接口。

将风扇ARGB线与冷头RGB线并联, 接在主板3针ARGB接口, 即可通过主板灯光软件来控制灯光。

冷头数据总线接在主板USB2.0的D+D-针接口

www.thermalright.com

冷头上盖操作说明

冷头磁吸设计, 可360°切换

将水冷头上盖旋转360度, 即可切换冷头朝向

www.thermalright.com

冷头上盖操作说明

冷头磁吸设计, 可360°切换

将水冷头上盖旋转360度, 即可切换冷头朝向

www.thermalright.com

冷头上盖操作说明

冷头磁吸设计, 可360°切换

将水冷头上盖旋转360度, 即可切换冷头朝向

www.thermalright.com

冷头上盖操作说明

冷头磁吸设计, 可360°切换

将水冷头上盖旋转360度, 即可切换冷头朝向

www.thermalright.com

FROZEN MAGIC DIGITAL控制软件说明

冷头磁吸设计, 可360°切换

将水冷头上盖旋转360度, 即可切换冷头朝向

www.thermalright.com

FROZEN MAGIC DIGITAL DISPLAY USER GUIDE

冷头磁吸设计, 可360°切换

将水冷头上盖旋转360度, 即可切换冷头朝向

www.thermalright.com

产品保修卡

冷头磁吸设计, 可360°切换

将水冷头上盖旋转360度, 即可切换冷头朝向

www.thermalright.com

产品保修卡

冷头磁吸设计, 可360°切换

将水冷头上盖旋转360度, 即可切换冷头朝向

www.thermalright.com

产品保修卡

冷头磁吸设计, 可360°切换

将水冷头上盖旋转360度, 即可切换冷头朝向

www.thermalright.com

产品保修卡

冷头磁吸设计, 可360°切换

将水冷头上盖旋转360度, 即可切换冷头朝向

www.thermalright.com