
成品尺寸: 95*105mm

展开尺寸: 190*105mm


FFLASHÍRE

MIZAR GAMING CONTROLLER 操作說明書









12 RT 14) 燈光鍵 15 編程按鍵

16 右-可被編程按鍵 ① 左-可被編程按鍵 18 3.5mm 耳機/麥克風

安裝說明:

- 1. F211 手把完美支援 Windows PC 10 及以上系統,即插即用,無需安裝驅動程式。
- 2. 打開 Windows PC 主機電源,將 F211 手把的 USB 插入任一可用的 USB 接口, Windows 10 或以上系統將自動加載驅動,等待安裝完成後手把中間的指示燈長 亮,表示手把已經連接成功並可正常使用。 *附註:3.5mm 接孔可連接耳機與麥克風

按鍵編程(映射)模式操作步驟:

- 1. 按住編程鍵 2 秒, LOGO 鍵呈發光慢閃表示手把己經進入按鍵編程模式。
- 2. 按下任一想要被編程(映射)的按鈕: A/B/X/Y/LB/RB/L3/R3/干字鍵, LOGO 鍵 呈發光快閃。
- 3. 按下左邊或右邊的編程鍵, LOGO鍵會由快閃變常亮,表示按鍵編程(映射)成功。 *注意:最多編程 16 個按鍵;超過 1 分鐘沒有設定將自動退出編程模式。
- 4. 如果要編程下一個按鈕,請重複以上3個步驟。

*注意:重新拔插 USB 後,將恢復初始狀態。

清除編程(映射)功能:

- 1. 按住編程鍵 2 秒, LOGO 鍵呈發光慢閃表示手把己經進入編程模式。
- 2. 再次按住編程鍵 5 秒, LOGO 鍵由慢閃變為長亮,表示編程 (映射) 功能已全部清除。

- 1. 按住 TURBO 鍵後再按一下需要作用的功能鍵,該鍵將成功對應手動連發功能。
- 2 重複上述步驟,該鍵將切換為白動連發功能。
- 3. 再次重複上述步驟,該鍵將取消連發功能。
- *注意:若需要暫停可在自動連發時按一下作用中的該功能鍵。

取消所有連發功能:

長按 TURBO 鍵 3 秒將清除所有按鍵的連發功能;重新拔插 USB 也可以取消所有已設定的 TURBO 功能。

連發速度設定:

按住手把 TURBO 鍵,同時進行右 3D 搖桿向上、向下操作,可進行連發速度調整,分為:快、 中、慢三檔,預設為慢檔。

左右搖桿 RGB 燈光模式調整:

- 1 燈光鍵 + R3: 模式調節,3種模式順序切換依序為: 常亮燈→呼吸跑馬燈→幻彩燈。 2. 燈光鍵 +13:
 - 常亮模式:可切換顏色
 - 呼吸跑馬燈模式:無作用
 - · 幻彩燈模式:固定顯示目前顏色/動態色彩切換
- 3. 同時長按 L3 + R3 鍵 3 秒,震動提示表示可以設定 RGB 光圈顏色;此時每短按一次 L3 鍵 可依次切換RGB 燈光顏色,順序為:七彩呼吸循環→藍色→紅色→粉紅色→橘色→黃 色 → 青色 → 紫色 → 關閉;當切換到想要的燈光顏色時,短按R3鍵確認且會有震動提示, 若未按 R3 鍵確認,手把 10 秒後會自動確認退出同時有震動提示。

FF FLASH IRE

MIZAR GAMING CONTROLLER **USER MENUAL** 240625 VO1



(2) I B ③ RB 4 View

 Sharing TURBO 10 D-PAD

① R3 ② RT ® LT

¹⁶ programmable-1 programmable-2
 3.5mm earphones / 14 Light-key microphone (§) Programming

DESCRIPTION OF MODES AND CONNECTION:

- 1. The F211 controller perfectly supports the Windows PC 10 or above system, without installing additional drivers.

 2. Turn on the power of the Windows PC, plug the USB cable of the F211 controller into any
- available USB hole and the middle indicator will be always ON after connection, indicating that the controller has been successfully connected and can be used normally. * Note: The 3.5mm audio port can be connected to the headset and the microphone

PROGRAMMING (MAPPING) MODE OPERATION STEPS:

- 1. Press the programming key for 2 seconds to start programming when the LOGO button
- 2. Press one or several buttons you want to set: A/B/X/Y/LB/RB/L3/R3/D-PAD, LOGO button is flashing quickly
- Press left or right programming key, and the LOGO light will change from flash quickly to flash constantly, indicating programming (mapping) buttons is completed. * Note: Maximum 16 keys for programming; programming mode will be closed automatically if setting is not completed within 1 minute.

- Please repeat above three steps if you want to program the next button.
 Remark: The function set previously will be cleared after unplugging the USB cable.

TO CLEAR THE PROGRAMMING (MAPPING) FUNCTION:

- 1. Press the programming key for 2 seconds, and the LOGO key is flashing slowly, indicating
- that the controller is entered into the programming mode.

 Press the programming key again for 5 seconds, and the LOGO light will change from flash slowly to flash constantly, indicating that programming (mapping) functions will be completely cleared.

TURBO FUNCTION:

- 1. Press TURBO button and then press one or several buttons you want to set to start manual TURBO function.
- Press the button with manual TURBO function again and then press TURBO button to start the automatic TURBO function 3. Press the button with automatic TURBO function again and then press TURBO button to
- clear TURBO function (When under automatic TURBO function mode, press the button with automatic TURBO function again to suspend this function)

CLEAR ALL TURBO:

Press and hold the TURBO button for more than 3 seconds or unplug the USB cable to clear the TURBO function

TURBO SPEED ADJUSTING:

Press TURBO button and then press UP of D-pad/DOWN of D-pad to adjust the speed included three levels of speed up/medium speed/slow down, the default is slow down.

RGB LIGHT MODE ADJUSTING:

- 1. Press RGB light control key and R3 to change mode, three modes in sequence: constantly light ON->breathing marquee light->Magical light
- *Constantly light ON mode: can change the light color

 *Breathing marquee light mode: no function

- *Magical light mode: display current color/multicolor dispaly

 Press and hold L3 with R3 for 3 seconds, vibration mean can set RGB light color; and then press L3 to change RGB light color in sequence: multicolor circular breathing->blue->red->pink->orange->yellow->cyan->purple->closed; when choosing RGB light color you want to change, press R3 for confirmation and have vibration, if without pressing R3 for confirmation within 10 seconds, this setting mode will be closed automatically and have vibration

