






Parts List



Intel Installation Guide




AMD Installation Guide





Installation Guide


1



2



3



CAUTION
To control the SEGMENT LCD display by SEGMENT LCD Software, Please connect the water block and motherboard with cable L.

CAUTION

Please power off the PC and check the Positive and Negative ends on the connector before connecting the cable to mainboard. Connecting the wrong end can damage the fans.

SEGMENT LCD Software Download

