









Dell S 27 QHD USB-C Monitor

S2725DC

Quick Start Guide















1





2


























Dell Display and Peripheral Manager  
[Dell.com/support/ddpm](https://Dell.com/support/ddpm)



[Dell.com/support/S2725DC](https://Dell.com/support/S2725DC)