



Air Power G10


User Manual

formulav-line.com





mini-ITX
micro-ATX
ATX


1




2




3




4




5 PSU Cover Configuration 1




6 PSU Cover Configuration 2




7 PSU into the Bracket




8 Fans onto the Fan Bracket







9 3.5 HDD




10 2.5 SSD




11 Install the AIO Radiator or Fans




12 Secure the Bracket




13 Install the Side Fans




14 GPU Support Bracket




15 Remove the Front Fan Cover




16 Tool-Free Removal



11 Adjust the Fan Position



12 I/O



Air Power G10

User Manual



MADE IN CHINA