THERMALRIGHT®
www.thermalright.com

用户手册

FROZEN HORIZON

注意！！！ 此付**HR**水冷都存在漏液风险，请谨慎
按规范操作安装！安装前请对水冷规进行详细检查，
开箱检查如有外观变形请立即联系客服进行确认！

REV:1.4

www.thermalright.com

THERMALRIGHT®
www.thermalright.com

USER MANUAL

FROZEN HORIZON

CAUTION!!! All liquid coolers has probability of leaking, breakdown caused by structures to install. ALWAYS check liquid coolers/pipe carefully, if there is anything of damaged or deformation to the connection/pipe, contact customer service immediately.

High Performance Water Pump
High Liquid Flow Rate Pump
High Density Aluminum Fins

REV1.4

www.thermalright.com

Components

www.thermalright.com

附件清单

www.thermalright.com

INTEL LGA 115X/17XX安装背板

配置的螺丝调整到对应主板所用的位置

www.thermalright.com

INTEL LGA 17XX Backplate Assemble

Installing solution 1 for LGA 1700/1851 series
Installing solution 2 for LGA 115X/1200 series

Adjust bolts position and screw to corresponding motherboard mounted positions

www.thermalright.com

INTEL Installation

www.thermalright.com

INTEL 安装

www.thermalright.com

INTEL LGA17XX/1851安装

www.thermalright.com

INTEL LGA1700/1851安装

www.thermalright.com

Intel LGA20XX安装

www.thermalright.com

INTEL LGA20XX MOUNTING

www.thermalright.com

AMD安装

www.thermalright.com

AMD Installation

www.thermalright.com

风扇与冷排安装

www.thermalright.com

Fan&Radiator Mounting

www.thermalright.com

冷头/风扇使用说明

■ 在主板上安装供电线BIOS设置

将冷头供电线插在主板CPU OPT或系统 PWM接口。
风扇供电线插在主板CPU (PWM)口。

冷头和风扇插在主板的3针MHW接口即可通过主板的灯光软件来控制灯效。

www.thermalright.com

Waterblock/Fan Guide

■ Connect waterblock's pump power cable to CPU_OPT or AIO PUMP socket

Connect fan power cable to CPU_FAN socket on motherboard.

■ Connect the 3-pin ARGB cable to motherboard's ARGB (digital) or (omnibit) lighting cable to 3-pin ARGB socket on motherboard.

www.thermalright.com

产品保修卡

用户姓名：_____

联系电话：_____

产品名称：_____

产品型号：_____

购买日期：_____

温馨提示：

感谢您选择使用 Thermalright 散热系列产品，为了能真正享受它出色的功效，请您仔细阅读本保修卡内容。

本公司出品之散热器产品在正常使用的情况下是长寿命，每产可以在周期长动转的条件下，本公司出品的散热器，所有零部件必须按照第三方规格，并保证了所承诺的指标参数值。

保修期： 1年，本产品不提供延长保修及扩展服务，LCP产品自广告配件日，此保修卡无效保修。

不予保证或不提供免费服务：

1.不能出示此保修卡，因遗失或其他原因无法证明产品的保修期限。
2.因自己安装不当造成的损坏产品不在保证范围。
3.由于用户不当使用造成的损坏，如使用过久，用户自理。
4.因使用不当造成的损坏，如使用过久，用户自理。
5.用户自行拆卸，维修或改变工作环境引起的损坏及故障。
6.使用环境不符合要求有关规定，如风扇安装空间
7.由因意外不可抗力，自然灾害等原因造成的损坏。
8.因过三年的保修期限的，或不符合产品使用要求造成的。
9.因使用不当，或使用不当，或使用不当，或使用不当，或使用不当。
10.从不予保修要求中更换下来的零件，对不完成的产品，概由其保
11.由保修卡中内容填写完整或不符合之处，以国家规定为准

生产厂商信息及LCP产品信息
DOSDIN：www.thermalright.com

惠普美科技有限公司
新北市新店区宁靖路45巷6弄2楼6F
电话：（02）2918-5123
邮箱：support@thermalright.com
邮编：231145

惠普美科技有限公司
生产厂商：LCP
产品型号：LCP-HR-SERIES
生产日期：