

# **PCIe 2/4-Port Gigabit SFP Network Adapter**

## **User Manual**

**Ver. 2.00**

**All brand names and trademarks are properties of their  
respective owners.**

# Contents:

<b>Chapter 1: Introduction .....</b>	<b>3</b>
1.1 Product Introduction .....	3
1.2 Features.....	3
1.3 Requirements .....	4
1.4 Package Contents .....	4
<b>Chapter 2: Getting Started.....</b>	<b>5</b>
2.1 Hardware Layout .....	5
2.2 Hardware Installation.....	6
2.3 Driver Installation.....	7
2.3.1 Installation for Windows .....	7
2.3.2 Installation for Linux .....	7
2.4 Verifying the installation .....	8
2.4.1 Verifying for Windows.....	8
2.4.2 Verifying for Linux.....	9

# Chapter 1: Introduction

## ***1.1 Product Introduction***

This PCIe 1G SFP Network Adapter is a cost-effective solution that delivers fast and reliable 1 Gbps network access at longer distances than copper-based networks. Using the SFP transceiver of your choice, you can connect your PCI Express-based server or workstation directly to your 1G fiber optic network.

## ***1.2 Features***

- Quad/Dual port 1G adapter
- Support common 1G SFP optical and Direct Attached Copper modules
- EEE (Energy Efficient Ethernet)
- Up to 9K Jumbo Frames
- IP, TCP and UDP checksum offloading (IPv4, IPv6) capabilities
- Designed to meet PCI Express Specification Revision 2.1
- One lane (x1) PCI Express compatible with x4, x8 and x16 PCI Express slots (for N-860)
- Two lanes (x2) PCI Express compatible with x8 and x16 PCI

Express slots (For N-630)

- IEEE 802.1Q Tagged VLAN
- Intel PROSet Utility for Microsoft Device Manager

## ***1.3 Requirements***

### Hardware

The following system specs are recommended minimum

- PCIe slot: Available 1-Lane/4-Lane PCI-Express slot Gen 2.0 or later
- Processor: Quad Core 3.0GHz or higher
- RAM: 4GB memory or higher

### Software

#### Operating systems supported (32/64 bits)

- Windows 10/11
- Windows Server 2012 R2/2016/2019/2022
- Linux 3.16 or later


## ***1.4 Package Contents***

- 1 x PCIe 2/4-Port Gigabit SFP Network Adapter
- 1 x User Manual


# Chapter 2: Getting Started

## 2.1 Hardware Layout

N-860:



N-630:



### **Link/Activity Indicator:**

<b>LED</b>	<b>Description</b>
<b>Link Speed LED</b>	Indicates Link Speed: <ul style="list-style-type: none"><li>• Solid Green = 1000Mbps</li></ul>
<b>Link /Activity LED</b>	Indicates Network Card Activity: <ul style="list-style-type: none"><li>• Solid Green = Network port is connected</li><li>• Flashing Green = Network port is active</li></ul>

## ***2.2 Hardware Installation***

1. Turn off the power to your computer.
2. Unplug the power cord and remove your computer's cover.
3. Remove the slot bracket from an available PCIe slot.
4. To install the card, carefully align the card's bus connector with the selected PCIe slot on the motherboard. Push the board down firmly.
5. Replace the slot bracket's holding screw to secure the card.
6. Secure the computer cover and reconnect the power cord.

## ***2.3 Driver Installation***

The following section shows you how to install PCIe 2/4-Port Gigabit SFP Network Adapter driver on different operating systems.

### **2.3.1 Installation for Windows**

1. Go to URL <http://www.sunrichtech.com.hk/>
2. Search N-630/N-860, download the driver.
3. Follow the on-screen instructions to finish installing the driver.

### **2.3.2 Installation for Linux**


1. Go to URL <http://www.sunrichtech.com.hk/>
2. Search N-630/N-860, download the driver.
3. Follow Readme.txt which is in the driver folder to finish installing the driver.

## 2.4 Verifying the installation


### 2.4.1 Verifying for Windows

1. Click on the “**Device Manager**” tab in the Windows Control Panel.

#### Start > Control Panel > Device Manager



2. Expand “**Network adapters**” item, and you can read “**Intel(R) I350 Gigabit Fiber Network Connection**” in the Device Manager.



## 2.4.2 Verifying for Linux

1. You can check whether the driver is loading by using following commands:

```
# lsmod | grep
```

```
# ifconfig -a
```

If there is a device name, ethX, shown on the monitor, the linux driver is load. Then, you can use the following command to activate the ethX.

```
# ifconfig ethX up, where X=0,1,2,...
```